



#### NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

#### LR2-DR2

Units: inches [mm]

Scale: Full

LR2 SERIES DIN RAIL ADAPTER, FOR USE  
WITH LR2-20P5-1PH, LR2-20P7, LR2-21P0,  
LR2-22P0, LR2-44XX - LR2-47XX, LR2-  
53XX - LR2-57XX LINE REACTORS

**AUTOMATIONDIRECT**.com