

NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

BX–08SIM

Units: inches [mm]

Scale: Full

BRX SIMULATOR INPUT MODULE, 8-POINT

AUTOMATIONDIRECT.com