





NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

SV2-CM-ENETIP

Units: mm [inches]

Scale: Full

SureServo2 COMMUNICATIONS MODULE, EtherNet/IP, (1) ETHERNET (RJ45) PORT, FOR USE WITH ALL SureServo2 DRIVES

AUTOMATIONDIRECT.com