



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

AUX11-E

Units: mm [inch]

Scale: Full

MERZ AUX. CONTACT: LEFT/RIGHT
SIDE MOUNT, 10A @ 600VAC

AUTOMATIONDIRECT.com