



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

BX-APAD
Units: inches [mm]
Scale: Full
BRX ACTIVE PADDING MODULE, ALLOWS EMULATION OF BRX MODULES IN I/O CONFIGURATION
 AUTOMATIONDIRECT .com