



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

CFW100-KHMIR

Units: inches [mm]

Scale: Full

CFW100 SERIES REMOTE SERIAL
HMI, FOR CFW100 SERIES AC
DRIVES, CFW100-CRS485 MODULE
AND USB CABLE INCLUDED

AUTOMATIONDIRECT.com