



SEE MANUAL FOR ASSEMBLY INSTRUCTIONS,
DETAILS, AND MOUNTING OPTIONS

NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

LAHP-ZB-25-25

Units: mm [inches]

Scale: Full

SUREMOTION MOUNTING
BRACKET: Z - LAHP-25 TO LAHP-25
SERIES ACTUATORS