



SEE MANUAL FOR ASSEMBLY INSTRUCTIONS,  
DETAILS, AND MOUNTING OPTIONS

#### NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

LAHP-ZB-25-33

Units: mm [inches]

Scale: Full

SUREMOTION MOUNTING  
BRACKET: Z - LAHP-25 TO LAHP-33  
SERIES ACTUATORS