



SEE MANUAL FOR ASSEMBLY INSTRUCTIONS, DETAILS, AND MOUNTING OPTIONS

NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

LAHP-ZB-33-33W

Units: mm [inches]

Scale: Full

SUREMOTION MOUNTING  
BRACKET: Z - LAHP-33 TO LAHP-  
33W SERIES ACTUATORS

**AUTOMATIONDIRECT**.com