



# NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

LR2-AP1

Units: inches [mm]

Scale: Full

LR2 SERIES ADAPTER PLATE, FOR  
USE WITH LR2-20P5-1PH, LR2-20P2,  
LR2-20P5, LR2-40XX - LR2-43XX, LR2-  
51XX - LR2-52XX LINE REACTORS

**AUTOMATIONDIRECT**.com