


NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

SG4-DONGLE
Units: mm [inches]
Scale: Full
DONGLE FOR PROGRAMMING SG4(-P)
 AUTOMATIONDIRECT .com