



Notes:

1. Dimensions can be changed by Manufacturer without notice.
2. Dimensions do not imply tolerance.

STQM0
Units: mm [inches] Scale: Full
SHUTTER, FOR THRU-BEAM QM SENSORS
 <b>AUTOMATIONDIRECT</b> <sup>®</sup>