



Pin-Connection

Pin Conn.		Pin M12-Connector	Assignment
1	to	1	Signal To Transmitter
2	to	2	Supply
3	to	3	Signal From Transmitter
4	to	4	GND



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

<p>XT-M12</p> <p>Units: mm [inches]</p> <p>Scale: Full</p> <p>ProSense ADAPTER, KEYED 4-PIN FEMALE TO 4-PIN M12, FOR USE WITH ProSense TEMPERATURE TRANSMITTER XTP SERIES AND XT-USB</p> <p> AUTOMATIONDIRECT LLC</p>
