



XTH-0100F-PT1

Units: inches [mm]

Scale: Full

TEMPERATURE TRANSMITTER
RTD Pt100 INPUT, HEAD MOUNT
0 - 100 DEG. F

 **AUTOMATIONDIRECT**.com